



## ThermoBond Cir-Kits

DESCRIPTION	PART NUMBERS
<p><b>ThermoBond Cir-Kit, Surface Mount Version</b></p> <p>Complete Consisting of:</p> <ul style="list-style-type: none"> <li>ThermoBond Frames (solder plated on one side):</li> <li>Chip Resistor/Capacitor</li> <li>Inductors, MELFs, Tantalum Capacitors</li> <li>SOTs</li> <li>SOICs, TSOPs</li> <li>PLCCs, LCCCs, SOJs, Ceramic QFPs, Basic Cir-Kit Material and Dry Film Adhesive for Custom Shaping/Cutting</li> <li>PQFPs</li> </ul> <p>Other Accessories:</p> <ul style="list-style-type: none"> <li>Abrasive Stick, 1 piece</li> <li>Kapton Tape, 12.7mm (0.5") x 76.2mm (3.0"), 10 pieces</li> <li>Provis Kit (for cutting and scraping)</li> <li>ThermoBond Tips</li> </ul>	<p><b>6993-0176</b></p> <p>1200-0147-01-P1</p> <p>1200-0148-01-P1</p> <p>1200-0149-01-P1</p> <p>1200-0150-01-P1</p> <p>1200-0151-01-P1</p> <p>1200-0152-01-P1</p> <p>7016-0003-P1</p>
<p><b>ThermoBond Cir-Kit, Thru-Hole Version</b></p> <p>Complete Consisting of:</p> <ul style="list-style-type: none"> <li>ThermoBond Frames (solder plated on one side):</li> <li>Straight Run</li> <li>Fine Traces</li> <li>Variety Frame</li> <li>Track Pad</li> <li>DIP Pad</li> <li>Lap/Trace Frames (solder plated on both sides):</li> <li>Straight Run</li> <li>Fine Traces</li> </ul> <p>Other Accessories:</p> <ul style="list-style-type: none"> <li>Eyelets and Funnelets (#'s 4, 5, 6, 8, 10, 21)</li> <li>Abrasive Stick, 1 piece</li> <li>Kapton Tape, 12.7mm (0.5") x 76.2mm (3.0"), 10 pieces</li> <li>Upper Setting Tool</li> <li>Setting Tool Guide</li> <li>Lower Setting Tool, Funnelet</li> <li>Support Tool Base</li> <li>Provis Kit (for cutting and scraping)</li> <li>ThermoBond Tips</li> </ul>	<p><b>6993-0179</b></p> <p>1200-0158-01-P1</p> <p>1200-0159-01-P1</p> <p>1200-0160-01-P1</p> <p>1200-0161-01-P1</p> <p>1200-0163-01-P1</p> <p>1200-0164-03-P1</p> <p>1200-0165-03-P1</p> <p>6000-0051</p> <p>6000-0054</p> <p>1132-0017-P1</p> <p>1321-0054</p> <p>7016-0003-P1</p>